



# FORM 2006

*design by Peter Schmidt*

**Designed by the artist Peter Schmidt, whose name is synonymous with lifestyle design, this collection draws inspiration from the circle and the square.**

**The interplay of the two elements creates a harmonious contrast on the white porcelain. The stackable pieces make this collection suitable to every buffet.**

Durch Kreise und Quadrate inspiriert, entwarf der Künstler Peter Schmidt, dessen Name als Synonym für Lifestyle und Design steht, die Form 2006. Das Zwischenspiel beider Elemente schafft einen harmonischen Kontrast auf weißem Porzellan. Die stapelbaren Geschirrteile sind ideale Begleiter für jede Art von Buffet.

Peter Schmidt, il cui nome è sinonimo di design di stili di vita, ha dato vita a Form 2006 traendo spunto dal cerchio e dal quadrato. Seppur in antitesi tra loro, queste geometrie creano un armonioso contrasto sulla candida porcellana. Gli articoli impilabili rendono la collezione perfetta per ogni tipo di buffet.

Peter Schmidt, connu pour le design des styles de vie, s'est inspiré au cercle et au carré pour la création de Form 2006. Même si ces formes sont opposées entre elles, ces deux géométries créent un contraste harmonieux sur la porcelaine blanche. Les articles empilables, rendent la collection adapté pour tout type de buffet.

# FORM 2006





# FORM 2006

**42006**  
SHAPE

**800001**  
DECOR: WHITE



**PLATE FLAT**

Teller flach  
Piatto piano  
Assiette plate

**10018** Ø 18 cm - Ø 7<sup>1</sup>/<sub>8</sub> in.

**10023** Ø 23 cm - Ø 9 in.

**10027** Ø 27 cm - Ø 10<sup>5</sup>/<sub>8</sub> in.

**10982** Ø 32 cm - Ø 12<sup>5</sup>/<sub>8</sub> in.



**PLATE DEEP**

Teller tief  
Piatto fondo  
Assiette creuse

**10124** Ø 24 cm - Ø 9<sup>1</sup>/<sub>2</sub> in.



**PLATE FLAT, SQUARE WELL**

Teller flach, Spiegel eckig  
Piatto piano, specchio quadrato  
Assiette plate, centre carré

**10024** Ø 24 cm - Ø 9<sup>1</sup>/<sub>2</sub> in.

**10028** Ø 28 cm - Ø 11 in.



**PLATTER OVAL, RECTANGULAR WELL**

Platte oval, Spiegel eckig  
Piatto ovale, specchio rettangolare  
Assiette ovale, centre rectangulaire

**12730** 30 x 15 cm - 11<sup>3</sup>/<sub>4</sub> x 5<sup>7</sup>/<sub>8</sub> in.

**12738** 38 x 19 cm - 15 x 7<sup>1</sup>/<sub>2</sub> in.

**Also used as sugar-creamer tray  
(12730)**



**SOUP CUP, STACKABLE**

Suppen-Obertasse, stapelbar  
Tazza brodo, impilabile  
Tasse à consommé, empilable

**10455 Cup** Ø 10 cm - h 6 cm - 0,35 L  
Ø 3<sup>7</sup>/<sub>8</sub> in. - h 2<sup>3</sup>/<sub>8</sub> in. - 11<sup>7</sup>/<sub>8</sub> oz.

**14851 Saucer** Ø 18 cm - Ø 7<sup>1</sup>/<sub>8</sub> in.



**SAUCEBOAT**

Sauciere  
Salsiera  
Saucière

**11622 Sauceboat 2 pcs.**

**13300 Bowl** Ø 10 cm - h 6 cm - 0,45 L  
Ø 3<sup>7</sup>/<sub>8</sub> in. - h 2<sup>3</sup>/<sub>8</sub> in. - 15<sup>1</sup>/<sub>4</sub> oz.

**10018 Plate flat** Ø 18 cm - Ø 7<sup>1</sup>/<sub>8</sub> in.



# FORM 2006

**42006**  
SHAPE

**800001**  
DECOR: WHITE



**BOWL**  
Schale  
Coppa  
Coupelle

**13300** Ø 10 cm - h 6 cm - 0,35L  
Ø 3<sup>7/8</sup> in. - h 2<sup>3/8</sup> in. - 11<sup>7/8</sup> in.



**BUTTER DISH**  
Buttergefäß  
Portaburro  
Beurrier

**15162** Ø 5 cm - h 6 cm - 0,07 L  
Ø 2 in. - h 2<sup>3/8</sup> in. - 2<sup>3/8</sup> oz.



**BOWL**  
Schüssel  
Insalatiera  
Saladier

**13321** Ø 21 cm - h 10 cm - 2,50 L  
Ø 8<sup>1/4</sup> in. - h 3<sup>7/8</sup> in. - 84<sup>1/2</sup> oz.

**13324** Ø 24 cm - h 11 cm - 3,70 L  
Ø 9<sup>1/2</sup> in. - h 4<sup>3/8</sup> in. - 125<sup>1/8</sup> oz.



**BOWL, STACKABLE**  
Schale, stapelbar  
Ciotola impilabile  
Bol empilable

**15270** Ø 10 cm - h 3 cm - 0,16 L - Ø 3<sup>7/8</sup> in. - h 1<sup>1/8</sup> in. - 5<sup>3/8</sup> oz.

**13371** Ø 10 cm - h 6 cm - 0,35 L - Ø 3<sup>7/8</sup> in. - h 2<sup>3/8</sup> in. - 11<sup>7/8</sup> oz.

**15271** Ø 24 cm - h 2,5 cm - Ø 9<sup>1/2</sup> in. - h 1 in.



suitable for

**15262 - 15263****BOWL SQUARE**

Schale quadratisch  
Coppetta quadrata  
Coupelle carré

**15262** 7 x 7 cm - h 2,5 cm - 2<sup>3</sup>/<sub>4</sub> x 2<sup>3</sup>/<sub>4</sub> in. - h 1 in.**15263** 7 x 7 cm - h 5 cm - 0,15 L  
2<sup>3</sup>/<sub>4</sub> x 2<sup>3</sup>/<sub>4</sub> in. - h 2 in. - 5<sup>1</sup>/<sub>8</sub> oz.**LID**

Deckel  
Coperchio  
Couvercle

**13543** 7 x 7 cm - 2<sup>3</sup>/<sub>4</sub> x 2<sup>3</sup>/<sub>4</sub> in.**BOWL SQUARE**

Schale quadratisch  
Ciotola quadrata  
Bol carré

**15264** Ø 15 x 15 cm - h 6 cm - 0,85 L  
Ø 5<sup>7</sup>/<sub>8</sub> x 5<sup>7</sup>/<sub>8</sub> in. - h 2<sup>3</sup>/<sub>8</sub> in. - 28<sup>3</sup>/<sub>4</sub> oz.**15265** Ø 15 x 15 cm - h 12 cm - 2,00 L  
Ø 5<sup>7</sup>/<sub>8</sub> x 5<sup>7</sup>/<sub>8</sub> in. - h 4<sup>3</sup>/<sub>4</sub> in. - 67<sup>5</sup>/<sub>8</sub> oz.**15267** Ø 18 x 18 cm - h 6 cm - 1,00 L  
Ø 7<sup>1</sup>/<sub>8</sub> x 7<sup>1</sup>/<sub>8</sub> in. - h 2<sup>3</sup>/<sub>8</sub> in. - 40<sup>5</sup>/<sub>8</sub> oz.**BOWL RECTANGULAR**

Schale rechteckig  
Ciotola rettangolare  
Bol rectangulaire

**15268** 7 x 14 cm - h 5 cm - 0,32 L  
2<sup>3</sup>/<sub>4</sub> x 5<sup>1</sup>/<sub>2</sub> in. - h 2 in. - 10<sup>7</sup>/<sub>8</sub> oz.**15269** 15 x 25 cm - h 6 cm - 1,70 L  
5<sup>7</sup>/<sub>8</sub> x 9<sup>7</sup>/<sub>8</sub> in. - h 2<sup>3</sup>/<sub>8</sub> in. - 57<sup>1</sup>/<sub>2</sub> oz.**BOWL RECTANGULAR, STACKABLE**

Schale rechteckig, stapelbar  
Ciotola rettangolare, impilabile  
Bol rectangulaire, empilable

**15272** 11 x 7 cm - h 4 cm  
4<sup>3</sup>/<sub>8</sub> x 2<sup>3</sup>/<sub>4</sub> in. - h 1<sup>5</sup>/<sub>8</sub> in.**KITCHEN FRIENDS****43330** **609993**  
SHAPE COLOUR: RED**AIRTIGHT LID FOR BOWL, PP**

Aromadeckel für Schale, PP  
Coperchio ermetico per ciotola, PP  
Couvercle hermétique pour coupe, PP

Not dishwasher safe

**Square****05655** 15 x 15 cm - 57/8 x 57/8 in.

Suitable for: 15264 - 15265

**05656** 18 x 18 cm - h - 71/8 x 71/8 in.

Suitable for: 15267

**Rectangular****05657** 15 x 25 cm - 57/8 x 97/8 in.

Suitable for: 15269

**609991**  
TRANSPARENT**609997**  
YELLOW**609993**  
RED**609982**  
TURQUOISE



# FORM 2006

**42006**  
SHAPE

**80001**  
DECOR: WHITE



**TEAPOT**

Teekanne  
Teiera  
Théière

**14235** 22,5 x 11,5 cm - h 14 cm - 1,6 L  
8<sup>7/8</sup> x 4<sup>1/2</sup> in. - h 5<sup>1/2</sup> in. - 54<sup>1/8</sup> oz.

**14232 Only lid** 13 x 7 cm - h 4,5 cm  
5<sup>1/8</sup> x 2<sup>3/4</sup> in. - h 1<sup>3/4</sup> in.

**TEAPOT**

Teekanne  
Teiera  
Théière

**14220**

19 x 8 cm - h 10,5 cm - 0,5 L  
7<sup>1/2</sup> x 3<sup>1/8</sup> in. - h 4<sup>1/8</sup> in. - 16<sup>7/8</sup> oz.

**14222 Only lid** 9,5 x 5 cm - h 3,5 cm  
3<sup>3/4</sup> x 2 in. - h 1<sup>3/8</sup> in.

**CREAMER**

Gießer  
Cremiera  
Crémier

**14420** Ø 6 cm - h 8,5 cm - 0,15 L  
Ø 2<sup>3/8</sup> in. - h 3<sup>3/8</sup> in. - 5<sup>1/8</sup> oz.

**14430** Ø 6 cm - h 10 cm - 0,20 L  
Ø 2<sup>3/8</sup> in. - h 3<sup>7/8</sup> in. - 6<sup>3/4</sup> oz.

**WARMER FOR TEAPOT 1,6 L**

Stövchen für Teekanne 1,6 L  
Réchaud per teiera 1,6 L  
Réchaud pour Théière 1,6 L

**15670** 18 x 12 cm - h 5,5 cm  
7<sup>1/8</sup> x 4<sup>3/4</sup> in. - h 2<sup>1/8</sup> in.

**DISH FOR TEA BAG**

Teebeutelbehälter  
Piattino per busta thé  
Coupelle pour sachet de thé

**15262**

7 x 7 cm - h 2,5 cm  
2<sup>3/4</sup> x 2<sup>3/4</sup> in. - h 1 in.

**SUGAR BOWL**

Zuckerdose  
Zuccheriera  
Sucrier

**14307** Ø 14 x 7 cm - h 5 cm - 0,28 L  
Ø 5<sup>1/2</sup> x 2<sup>3/4</sup> in. - h 2 in. - 9<sup>1/2</sup> oz.

**14309 Only lid** 14 x 7 cm - 5<sup>1/2</sup> x 2<sup>3/4</sup> in.

# FORM 2006

**42006**  
SHAPE

**800001**  
DECOR: WHITE



**CUP**  
Obertasse  
Tazza  
Tasse

**16715** Ø 5 cm - h 6 cm - 0,07 L  
Ø 2 in. - h 2<sup>3</sup>/<sub>8</sub> in. - 2<sup>3</sup>/<sub>8</sub> oz.



**CUP**  
Obertasse  
Tazza  
Tasse

**16712** Ø 5 cm - h 8,5 cm - 0,10 L  
Ø 2 in. - h 3<sup>3</sup>/<sub>8</sub> in. - 3<sup>3</sup>/<sub>8</sub> oz.



**CUP**  
Obertasse  
Tazza  
Tasse

**14742** Ø 6,5 cm - h 8,5 cm - 0,20 L  
Ø 2<sup>1</sup>/<sub>2</sub> in. - h 3<sup>3</sup>/<sub>8</sub> in. - 6<sup>3</sup>/<sub>4</sub> oz.



**CUP**  
Obertasse  
Tazza  
Tasse

**14642** Ø 9 cm - h 5 cm - 0,20 L  
Ø 3<sup>1</sup>/<sub>2</sub> in. - h 2 in. - 6<sup>3</sup>/<sub>4</sub> oz.



**CUP**  
Obertasse  
Tazza  
Tasse

**14852** Ø 10 cm - h 6 cm - 0,35 L  
Ø 3<sup>7</sup>/<sub>8</sub> in. - h 2<sup>3</sup>/<sub>8</sub> in. - 11<sup>7</sup>/<sub>8</sub> oz.



**MUG**  
Becher  
Mug  
Gobelet

**15505** Ø 9 cm - h 9 cm - 0,40 L  
Ø 3<sup>1</sup>/<sub>2</sub> in. - h 3<sup>1</sup>/<sub>2</sub> in. - 13<sup>1</sup>/<sub>2</sub> oz.



**CUP, STACKABLE**  
Obertasse, stapelbar  
Tazza impilabile  
Tasse empilable

**16718** Ø 5,5 cm - h 6 cm - 0,07 L  
Ø 2<sup>1</sup>/<sub>8</sub> in. - h 2<sup>3</sup>/<sub>8</sub> in. - 2<sup>3</sup>/<sub>8</sub> oz.



**CUP TALL, STACKABLE**  
Obertasse hoch, stapelbar  
Tazza alta, impilabile  
Tasse haute, empilable

**16730** Ø 5,5 cm - h 8,5 cm - 0,11 L  
Ø 2<sup>1</sup>/<sub>8</sub> in. - h 3<sup>3</sup>/<sub>8</sub> in. - 3<sup>3</sup>/<sub>4</sub> oz.



**CUP TALL, STACKABLE**  
Obertasse hoch, stapelbar  
Tazza alta, impilabile  
Tasse haute, empilable

**16747** Ø 6,5 cm - h 8,5 cm - 0,20 L  
Ø 2<sup>1</sup>/<sub>2</sub> in. - h 3<sup>3</sup>/<sub>8</sub> in. - 6<sup>3</sup>/<sub>4</sub> oz.



**CUP, STACKABLE**  
Obertasse, stapelbar  
Tazza impilabile  
Tasse empilable

**16647**  
Ø 8,5 cm - h 5 cm - 0,20 L  
Ø 3<sup>3</sup>/<sub>8</sub> in. - h 2 in. - 6<sup>3</sup>/<sub>4</sub> oz.



**CUP, STACKABLE**  
Obertasse, stapelbar  
Tazza impilabile  
Tasse empilable

**16756**  
Ø 10 cm - h 6 cm - 0,32 L  
Ø 3<sup>7</sup>/<sub>8</sub> in. - h 2<sup>3</sup>/<sub>8</sub> in. - 10<sup>7</sup>/<sub>8</sub> oz.



**MUG, STACKABLE**  
Becher, stapelbar  
Mug impilabile  
Gobelet empilable

**15491**  
Ø 9 cm - h 9 cm - 0,40 L  
Ø 3<sup>1</sup>/<sub>2</sub> in. - h 3<sup>1</sup>/<sub>2</sub> in. - 13<sup>1</sup>/<sub>2</sub> oz.

suitable for

14742 - 16747



**SAUCER**  
Untertasse  
Piattino  
Soucoupe

**14741** Ø 14 cm - Ø 5<sup>1/2</sup> in.

suitable for

14642 - 15491  
15505 - 16647



**SAUCER**  
Untertasse  
Piattino  
Soucoupe

**14641** Ø 16 cm - Ø 6<sup>1/4</sup> in.

suitable for

14852 - 16756



**SAUCER**  
Untertasse  
Piattino  
Soucoupe

**14851** Ø 18 cm - Ø 7<sup>1/8</sup> in.

suitable for

16712 - 16715  
16718 - 16730



**SAUCER**  
Untertasse  
Piattino  
Soucoupe

**16711** 18 x 9 cm - 7<sup>1/8</sup> x 3<sup>1/2</sup> in.

suitable for

16718 - 16730 - 16747



**SAUCER, COMBI**  
Untertasse, combi  
Piattino combi  
Soucoupe combi

**16752** 18 x 9 cm - 7<sup>1/8</sup> x 3<sup>1/2</sup> in.

suitable for

16718 - 16730 - 16747



**SAUCER, COMBI**  
Untertasse, combi  
Piattino combi  
Soucoupe combi

**16749** Ø 14 cm - Ø 5<sup>1/2</sup> in.

suitable for

15491 - 16647



**SAUCER, COMBI**  
Untertasse, combi  
Piattino combi  
Soucoupe combi

**16649** Ø 16 cm - Ø 6<sup>1/4</sup> in.