

Time

TIME
Design Dieter A. Grabe
hotel
Time

Elegant, Timeless, Distinctive

TIME/TIME SQUARE is one of our most famous and successful creations. Whether you prefer the plain design of TIME or the characteristic structure of TIME SQUARE, you will enjoy the refinement of the shape and its great variety and functionality day by day.

Elegant, Zeitlos, Unverkennbar.

TIME/TIMESQUARE ist eine unserer bekanntesten und erfolgreichsten Kreationen. Ganz egal, ob Ihnen die glatte Tellerform TIME oder das unverwechselbare Reliefdesign von TIME SQUARE näher liegt: Die Raffinesse der Form, verbunden mit grosser Vielseitigkeit und Funktionalität, wird Sie Tag für Tag begeistern.



Time



TIM2131
plate flat / Teller flach
31 cm



TIM2129
plate flat / Teller flach
29 cm



TIM2127
plate flat / Teller flach
27 cm



TIM2125
plate flat / Teller flach
25 cm



TIM2121
plate flat / Teller flach
21 cm



TIM2116
plate flat / Teller flach
16 cm



TIM1922
plate deep / Teller tief
22 cm



TIM3038
platter / Platte
38/28 cm



TIM1919
plate deep / Teller tief
19 cm



TIM1917
plate deep / Teller tief
17 cm



TIM3032
platter / Platte
32/23 cm



Time square



SQU2131
plate flat / Teller flach
31 cm



SQU2121
plate flat / Teller flach
21 cm



SQU2127
plate flat / Teller flach
27 cm



SQU2116
plate flat / Teller flach
16 cm



SQU1922
plate deep / Teller tief
22 cm



Time

TIM0211
cup / Tasse
11 cl



TIM1713
saucer / Untertasse
13 cm



TIM0220
cup / Tasse
20 cl



TIM0223
cup / Tasse
23 cl



TIM0030
mug / Becher
30 cl



TIM1716
saucer / Untertasse
16 cm



TIM1720
saucer / Untertasse
16 cm



SQU1716
saucer / Untertasse
16 cm



TIM0819
cup / Tasse
19 cl



TIM0628
mug / Becher
28 cl

TIM0209
cup / Tasse
9 cl



TIM1711
saucer / Untertasse
13 cm



TIM0218
cup / Tasse
18 cl

SQU1713
saucer / Untertasse
13 cm



Time

TIM1124
soup cup / Suppentasse
24 cl



TIM1716
saucer / Untertasse
16 cm

TIM1720
saucer / Untertasse
16 cm

SQU1716
saucer / Untertasse
16 cm

TIM1133
soup cup / Suppentasse
33 cl



TIM5001
salt shaker
Salzstreuer



TIM5011
pepper shaker
Pfefferstreuer



TIM1424
bowl / Schale
370 cl / 24 cm



TIM1421
bowl / Schale
260 cl / 21 cm



TIM1418
bowl / Schale
170 cl / 18 cm



TIM1413
bowl / Schale
71 cl / 13 cm



TIM3515
creamer / Giesser
15 cl



TIM3530
creamer / Giesser
30 cl



TIM3603
creamer / Giesser
3 cl

TIM3930
lid / Deckel



TIM3830
coffee pot / Kaffeekanne
30 cl

TIM3950
lid / Deckel



TIM3850
coffee pot / Kaffeekanne
50 cl



TIM3960
lid / Deckel

TIM3710
coffee pot / Kaffeekanne
1 l

TIM3960
lid / Deckel



TIM4160
tea pot / Teekanne
60 cl

TIM4502
lid / Deckel



TIM4302
sugar bowl / Zuckerdose
28 cl / 10 cm

TIM3950
lid / Deckel



TIM4140
tea pot / Teekanne
40v cl