

# LOFT by Rosenthal

DESIGN BY QUEENSBERRY & HUNT



**Delicate concentric texture**

-

**Contemporary and trendy**

-

**Round and square plates**

-

**Space saver rectangular plate for seafood entrée**

-

**Suggested with Sambonet cutlery FLAT in PVD color**

Zarte, konzentrische Struktur

-

Zeitgemäß und trendy

-

Runde und quadratische Teller

-

Platz sparende, rechteckige Platte, besonders geeignet für Fischgerichte

-

Perfekt kombiniert mit Sambonet-Besteck der Kollektion Flat in PVD-Finish

Delicata trama concentrica

-

Contemporaneo e trendy

-

Piatti rotondi e quadrati

-

Piatto rettangolare perfetto per piatti unici di pesce

-

Al suo meglio con posate Sambonet Flat in finitura PVD

Délicate trame concentrique

-

Contemporaine et tendance

-

Assiettes rondes et carrées

-

Assiette rectangulaire idéale pour des plats de poisson uniques

-

S'accorde parfaitement avec les couverts Sambonet Flat finition PVD





LOFT by Rosenthal

PORCELAIN THOMAS - LOFT BY ROSENTHAL  
HOLLOWARE SAMBONET - SPHERA AND LINEA Q PVD RUM  
CUTLERY SAMBONET - LINEA Q ANTIQUE PVD COPPER





# LOFT by Rosenthal

SHAPE / FORM / FORMA / FORME  
11900

DECOR / DEKOR / DECORO / DÉCORATION  
800001 WHITE

 Microwave-safe

 Dishwasher safe



## Plate flat

Teller flach  
Piatto piano  
Assiette plate

**10218** Ø 18 cm - Ø 7 in.  
**10222** Ø 22 cm - Ø 8<sup>2</sup>/<sub>3</sub> in.  
**10229** Ø 28 cm - Ø 11 in.  
**10871** Ø 31 cm - Ø 12<sup>1</sup>/<sub>4</sub> in.  
**10263** Ø 33 cm - Ø 13 in.



## Gourmet plate

Gourmetteller  
Piatto gourmet  
Gourmet assiette coupe

**10733** Ø 33 cm - Ø 13 in.



## Plate deep

Teller tief  
Piatto fondo  
Assiette creuse

**10324** Ø 24 cm - Ø 9<sup>1</sup>/<sub>2</sub> in.



## Platter deep square

Platte tief quadratisch  
Piatto fondo quadrato  
Assiette creuse et quadratique

**12072** 22 x 22 cm - 8<sup>2</sup>/<sub>3</sub> x 8<sup>2</sup>/<sub>3</sub> in.



## Platter flat oval

Platte flach oval  
Piatto piano ovale  
Assiette plate et ovale

**12734** 34 x 24 cm - 13<sup>1</sup>/<sub>2</sub> x 9<sup>1</sup>/<sub>2</sub> in.  
**12740** 40 x 28 cm - 16 x 11 in.



## Platter / Plate flat square

Platte/Teller flach quadratisch  
Piatto piano quadrato  
Assiette plate et quadratique

**15258** 13 x 13 cm - 5<sup>1</sup>/<sub>8</sub> x 5<sup>1</sup>/<sub>8</sub> in.  
**12019** 19 x 19 cm - 7<sup>1</sup>/<sub>2</sub> x 7<sup>1</sup>/<sub>2</sub> in.  
**12027** 27 x 27 cm - 10<sup>5</sup>/<sub>8</sub> x 10<sup>5</sup>/<sub>8</sub> in.  
**16531** 33 x 33 cm - 13 x 13 in.



## Platter rectangular

Platte rechteckig  
Piatto rettangolare  
Assiette rectangulaire

**12881** 39x25 cm - 15<sup>1</sup>/<sub>3</sub> x 9<sup>7</sup>/<sub>8</sub> in.



## Rectangular plate divided

Teller rechteckig geteilt  
Piatto rettangolare diviso  
Assiette rectangulaire divisé

**16541** 28 x 15 cm - 11 x 6 in.



### Etagere 3-part round

Etagere rund 3-tlg.  
Etagere 3-piani rotonda  
Etagère en 3 parties rondes

**25313** Ø 12 · 19 · 27 cm H 29 cm  
Ø 4¾ · 7½ · 10⅝ in. H 11⅜ in.



### Bowl low round

Schüssel nieder rund  
Coppa bassa tonda  
Bol basse ronde

**13123** Ø 23 cm H 11 cm  
Ø 9 in. H 4⅜ in.

**13524 Lid**



### Bowl tall round

Schüssel hoch rund  
Coppa alta tonda  
Bol haut rond

**13323** Ø 23 cm H 16 cm  
Ø 9 in. H 6¼ in.

**13524 Lid**



### Platter deep oval

Platte tief oval  
Piatto fondo ovale  
Assiette creuse et ovale

**12527** 27 x 19 cm  
10⅝ x 7½ in.



### Bowl deep oval

Bowl tief oval  
Coppa fonda ovale  
Coupe creuse et ovale

**10575** 17 x 12,5 cm H 6,5 cm  
6⅔ x 4⅞ in. H 2½ in.



### Bowl deep round

Bowl tief rund  
Coppa fonda rotonda  
Coupelle creuse ronde

**10571** Ø 13 cm H 6,5 cm  
Ø 5⅜ in. H 2½ in.

**10570** Ø 15 cm H 7,5 cm  
Ø 6 in. H 3 in.



### Bowl deep square

Schüssel quadratisch tief  
Coppa fonda quadrata  
Bol creux et carré

**10585** 12 x 12 cm H 3,5 cm  
4¾ x 4¾ in. H 1⅜ in.

**10586** 15 x 15 cm H 6,5 cm  
6 x 6 in. H 2½ in.

**13071** 21 x 21 cm H 10,5 cm  
8¼ x 8¼ in. H 4⅞ in.

# LOFT by Rosenthal

SHAPE / FORM / FORMA / FORME  
11900

DECOR / DEKOR / DECORO / DÉCORATION  
800001 WHITE



**Cereal dish**  
Müslischale  
Coppetta cereali  
Bol céréales

**15453** Ø 13 cm H 7 cm - Ø 5<sup>1</sup>/<sub>8</sub> cm H 2<sup>3</sup>/<sub>4</sub> cm



**Saucer cereal bowl**  
Untertasse Müslischale  
Piattino coppetta cereali  
Soucoupe bol cereales

**15581** 26 x 16 cm - 10<sup>1</sup>/<sub>4</sub> x 3<sup>3</sup>/<sub>8</sub> in.



**Base for teapot**  
Teekannen-Unterteil  
Teiera senza coperchio  
Base pour théière

**34211** H 8 cm 0,40L  
H 3<sup>1</sup>/<sub>8</sub> in. 14 oz.



**Lid**  
Deckel  
Coperchio  
Couvercle

**34212** H 4,5 cm - H 1<sup>3</sup>/<sub>4</sub> in.



**Creamer**  
Gießer  
Lattiera  
Crémier

**34415** Ø 7 cm H 7 cm 0,15L - Ø 2<sup>3</sup>/<sub>4</sub> in. H 2<sup>3</sup>/<sub>4</sub> in. 5<sup>1</sup>/<sub>4</sub> oz.  
**34430** Ø 8 cm H 8,5 cm 0,30L - Ø 3<sup>1</sup>/<sub>8</sub> in. H 3<sup>3</sup>/<sub>8</sub> in. 10<sup>1</sup>/<sub>2</sub> oz.



**Sugar bowl with lid**  
Zuckerdose mit Deckel  
Zuccheriera con coperchio  
Sucrier avec couvercle

**14330** Ø 8 cm H 7 cm 0,26L  
Ø 3<sup>1</sup>/<sub>8</sub> in. H 2<sup>3</sup>/<sub>4</sub> in. 8 oz.

**Lid**  
Deckel  
Coperchio  
Couvercle

**14332** Ø 8,5 cm H 4 cm  
Ø 3<sup>3</sup>/<sub>8</sub> in. H 1<sup>5</sup>/<sub>8</sub> in.



**Cup stackable**  
Obertasse stapelbar  
Tazza impilabile  
Tasse empilable

**16727** Ø 6 cm H 6 cm 0,11L  
Ø 2<sup>3</sup>/<sub>8</sub> in. H 2<sup>3</sup>/<sub>8</sub> in. 3<sup>7</sup>/<sub>8</sub> oz.  
**16726 Saucer** Ø 12,5 cm - Ø 5 in.



**Cup stackable**  
Obertasse stapelbar  
Tazza impilabile  
Tasse empilable

**16747** Ø 7,5 cm H 7,5 cm 0,20L  
Ø 3 in. H 3 in. 7 oz.  
**16746 Saucer** Ø 16,5 cm - Ø 6<sup>1</sup>/<sub>2</sub> in.

SUITABLE FOR  
**16647 - 15573 - 15574**



**Saucer**  
Untertasse  
Piattino  
Soucoupe

**16646** Ø 16,5 cm - Ø 6<sup>1</sup>/<sub>2</sub> in.



**Cup stackable**  
Obertasse stapelbar  
Tazza impilabile  
Tasse empilable

**16647** Ø 8,5 cm H 6 cm 0,21L  
Ø 3<sup>3</sup>/<sub>8</sub> in. H 3<sup>3</sup>/<sub>8</sub> in. 7<sup>1</sup>/<sub>2</sub> oz.



**Mug with handle stackable**  
Becher mit Henkel stapelbar  
Mug con manico impilabile  
Gobelet avec anse empilable

**15573** Ø 8,5 cm H 8,5 cm 0,33L  
Ø 3<sup>3</sup>/<sub>8</sub> in. H 3<sup>3</sup>/<sub>8</sub> in. 11 oz.  
**15574** Ø 8,5 cm H 10 cm 0,38L  
Ø 3<sup>3</sup>/<sub>8</sub> in. H 3<sup>3</sup>/<sub>8</sub> in. 12<sup>3</sup>/<sub>4</sub> oz.



**Cup**  
Obertasse  
Tazza  
Tasse

**14717** Ø 7 cm H 5 cm 0,08L  
Ø 2<sup>3</sup>/<sub>4</sub> in. H 2 in. 2<sup>7</sup>/<sub>8</sub> oz.  
**14716 Saucer** Ø 11,5 cm - Ø 4<sup>1</sup>/<sub>2</sub> in.



**Cup**  
Obertasse  
Tazza  
Tasse

**14642** Ø 10 cm H 6 cm 0,25L  
Ø 3<sup>7</sup>/<sub>8</sub> in. H 2<sup>3</sup>/<sub>8</sub> in. 8<sup>7</sup>/<sub>8</sub> oz.  
**14641 Saucer** Ø 16,5 cm - Ø 6<sup>1</sup>/<sub>2</sub> in.



**Cup**  
Obertasse  
Tazza  
Tasse

**14772** Ø 11 cm H 6,5 cm 0,34L  
Ø 4<sup>3</sup>/<sub>8</sub> in. H 3 in. 12 oz.  
**14771 Saucer** Ø 18 cm - Ø 7 in.



# LOFT

SHAPE / FORM / FORMA / FORME  
10410

DECOR / DEKOR / DECORO / DÉCORATION  
800001 WHITE



Microwave-safe



Dishwasher safe



### Plat flat rectangular

Platte flach rechteckig  
Piatto piano rettangolare  
Plat rectangulaire

**12918** 18 x 13 cm - 7 x 5<sup>1</sup>/<sub>8</sub> in.  
**12928** 28 x 18 cm - 11 x 7 in.



### Platter/Plate flat square

Platte/Teller flach quadratisch  
Piatto piano quadrato  
Plat carré

**12922** 22 x 22 cm - 8<sup>2</sup>/<sub>3</sub> x 8<sup>2</sup>/<sub>3</sub> in.



### Dish square

Schale quadratisch  
Coppa quadrata  
Coupe quadratique

**12965** 15 x 15 cm H 3,5 cm  
6 x 6 in. H 1<sup>3</sup>/<sub>8</sub> in.



### Chopstick holder

Chopstickhalter  
Portabacchette  
Support de baguettes

**15535** 7 x 2 cm  
2 <sup>3</sup>/<sub>4</sub> x <sup>3</sup>/<sub>4</sub> in.

SHAPE / FORM / FORMA / FORME  
10410 without relief



### Platter rectangular

Platte flach rechteckig  
Piatto piano rettangolare  
Plat rectangulaire

**32679** 29 x 19 cm - 11<sup>1</sup>/<sub>2</sub> x 7<sup>1</sup>/<sub>2</sub> in.



### Bowl deep square

Schälchen tief quadratisch  
Piattino fondo quadrato  
Bol creux carré

**35480** 13 x 13 cm - 5<sup>1</sup>/<sub>8</sub> x 5<sup>1</sup>/<sub>8</sub> in.

SHAPE / FORM / FORMA / FORME  
11940 without relief



### Plate flat square

Teller flach quadratisch  
Piatto piano quadrato  
Assiette plate carrée

**16183** 23 x 23 cm - 9 x 9 in.  
**16188** 28 x 28 cm - 11 x 11 in.



### Bowl deep square

Schälchen tief quadratisch  
Piattino fondo quadrato  
Bol creux carré

**15252** 9 x 9 cm - 3<sup>1</sup>/<sub>2</sub> x 3<sup>1</sup>/<sub>2</sub> in.  
**15254** 12 x 12 cm - 4<sup>3</sup>/<sub>4</sub> x 4<sup>3</sup>/<sub>4</sub> in.



### Dish flat square

Schälchen flach quadratisch  
Piattino piano quadrato  
Bol plat carré

**15253** 12 x 12 cm - 4<sup>3</sup>/<sub>4</sub> x 4<sup>3</sup>/<sub>4</sub> in.



### Platter flat rectangular

Platte flach rechteckig  
Piatto piano rettangolare  
Plat rectangulaire

**12718** 18 x 11 cm - 7 x 4<sup>3</sup>/<sub>8</sub> in.



### Plate deep square

Teller tief quadratisch  
Piatto fondo quadrato  
Assiette creuse carrée

**16513** 23 x 23 cm - 9 x 9 in.

# Thomas

HOTEL & RESTAURANT SERVICE

LOFT by Rosenthal



COFFEEWARE THOMAS - LOFT BY ROSENTHAL  
CUTLERY SAMBONET - LINEA Q ANTIQUE PVD COPPER  
HOLLOWARE SAMBONET - LINEA Q & SPHERA PVD RUM  
TRAY SAMBONET - TOKYO  
GLASSES ROSENTHAL - DIVINO