



the flag ship of G. Benedikt

PRINCIP





DID 2131
plate flat 31 cm



PRI 2128
plate flat 28 cm



PRI 2127
plate flat 27 cm



PRI 2131
coup plate 31 cm



PRI 2124
plate flat 24 cm



PRI 2121
plate flat 21 cm



PRI 2119
plate flat 19 cm



PRI 2117
plate flat 17 cm



PRI 2115
plate flat 15 cm



PRI 3024
oval plate 24 cm



PRI 3032
oval plate 32 cm



PRI 3036
oval plate 36 cm



PRI 1413
bowl 13 cm



PRI 1416
bowl 16 cm



PRI 1420
bowl 20 cm



PRI 1423
bowl 23 cm



PRI 1923
plate deep 23 cm



PRI 3310
gravy boat 10 cl

PRI 3325
gravy boat 25 cl



PRI 3602
creamer 2 cl



PRI 3604
creamer 4 cl



PRI 4302
sugar box 20 cl

PRI 4502
cover



PRI 4402
cover

PRI 4302
mustard pot 20 cl



PRI 4610
vase 10 cm



PRI 2108
plate flat 8 cm



PRI 3925
cover

PRI 3825
coffee pot 25 cl



PRI 3960
cover

PRI 3860
coffee pot 60 cl



PRI 3912
cover

PRI 3712
coffee pot 1.2 l



PRI 5000
salt shaker



PRI 5030
pepper shaker



PRI 2914
support



PRI 4906
toothpick holder



PRI 3960
cover

PRI 4130
tea pot 30 cl



PRI 3960
cover

PRI 4145
tea pot 45 cl



PRI 4275
cover

PRI 4175
tea pot 75 cl



PRI 4212
cover

PRI 4012
tea pot 1.2 l