

ISABELLE coup

Design M. Machek

fine dining

Isabelle

A new way of porcelain without rim. ISABELLE COUP lives out ease and sophistication of the contemporary fine dining culture. The rimless and free flowing design will turn dining into a remarkable experience. Whether you prefer pure white, matt glazing or nice decorations – the stage is yours.

Porzellan ohne Fahne neu definiert. ISABELLE COUPE zelebriert die Leichtigkeit und Raffinesse der zeitgenössischen Tafelkultur. Randlose und weich fließende Formen machen das Essen zum Erlebnis. Ganz egal, ob Sie lieber pures Weiss, matt glasiert oder fein dekoriert bevorzugen – Die Bühne gehört Ihnen.



Isabelle



ISC2130
plate flat / Teller flach
30 cm



ISC2127
plate flat / Teller flach
27 cm



ISC2116
plate flat / Teller flach
16 cm



ISC2121
plate flat / Teller flach
21 cm



ISC2124
plate flat / Teller flach
24 cm



DIV2134
plate flat / Teller flach
34 cm



ISC1929
plate deep / Teller tief
29 cm



ISC1917
bowl / Schale
17 cm



ISC1923
plate deep / Teller tief
23 cm



ISC1913
bowl / Schale
13 cm



ISC1926
pasta plate / Pastateller
26 cm



Isabelle



ISC3020
oval plate / Platte oval
20 cm



ISC3028
oval plate / Platte oval
28 cm



ISC3032
oval plate / Platte oval
32 cm



ISC1518
deep oval plate / Platte oval tief
18 cm



ISC1526
deep oval plate / Platte oval tief
26 cm



ISC1530
deep oval plate / Platte oval tief
30 cm



ISB9412
votive / Kerzenhalter



ISB5000 / ISB5030
salt shaker & pepper shaker
Salzstreuer & Pfefferstreuer



ISB9418
oil & vinegar
Karaffe Öl, Essig
18 cl



ISL2119
plate flat / Teller flach
19 cm



ISL2123
plate flat / Teller flach
23 cm



ISL2127
plate flat / Teller flach
27 cm



ISC1415
bowl / Schüssel
15 cm



ISC0309
bowl / Schüssel
7 cm



DIV1929
pasta plate / Pastateller
29 cm




ISC1413
bowl / Schüssel
13 cm



ISC1416
bowl / Schüssel
16 cm

ISABELLE coup





Isabelle

- 

ISB0622
coffee cup / Tasse
22 cl
- 

ISB0808
espresso cup / Tasse
8 cl
- 

ISC0815
coffee cup / Tasse
15 cl
- 

ISC1816
saucer / Untertasse
16 cm
- 

AMB1714
saucer / Untertasse
14 cm
- 

ISB1711
saucer / Untertasse
11 cm
- 

ISB0825
tea cup / Tasse
15 cl
- 

ISC1816
saucer / Untertasse
16 cm
- 

ISB1714
saucer / Untertasse
14 cm
- 

ISC0309
jasmin tea / Tasse
9 cl
- 

ISB3608
creamer / Giesser
8 cl
- 

ISB1711
saucer / Untertasse
11 cm
- 

ISB4212
lid / Deckel
- 

ISB4260
lid / Deckel
- 

ISB4160
pot / Kanne
60 cl
- 

ISB4260
lid / Deckel
- 

ISC4145
tea pot / Teekanne
45 cl
- 

ISC0835
tea cup / Tasse
35 cl
- 

ISC835
tea cup / Tasse
35 cl
- 

ISC1716
saucer / Untertasse
16 cm
- 


ISC4141
combo set
- 

ISC1716
saucer / Untertasse
16 cm

X8753



Vintage




ISC2130
plate flat / Teller flach
30 cm

ISC2127
plate flat / Teller flach
27 cm

ISC2124
plate flat / Teller flach
24 cm

ISC2121
plate flat / Teller flach
21 cm

ISC2116
plate flat / Teller flach
16 cm



CHC3032
oval plate / Platte oval
32 cm

ISC3032
oval plate / Platte oval
32 cm

ISC3028
oval plate / Platte oval
28 cm

CHC3028
oval plate / Platte oval
28 cm



CHC2130
plate flat / Teller flach
30 cm

CHC2127
plate flat / Teller flach
27 cm

CHC2124
plate flat / Teller flach
24 cm

CHC2121
plate flat / Teller flach
21 cm

CHC2116
plate flat / Teller flach
16 cm



CHC1926
pasta plate / Pastateller
26 cm



ISB9418
oil & vinegar
Karaffe Öl, Essig
18cl



CHC3020
oval plate / Platte oval
20 cm




ISC3020
oval plate / Platte oval
20 cm



CHC1416
bowl / Schale
16 cm



CHC1413
bowl / Schale
13 cm



CHC4260
lid / Deckel

CHC4160
pot / Kanne
60 cl




CHC0825
tea cup / Tasse
15 cl



CHC0815
coffee cup / Tasse
15 cl



ISC1816
saucer / Untertasse
16 cm



Points X8821
Points



ISC2130 plate flat / Teller flach 30 cm
 ISC2127 plate flat / Teller flach 27 cm
 ISC2124 plate flat / Teller flach 24 cm
 ISC2121 plate flat / Teller flach 21 cm
 ISC2116 plate flat / Teller flach 16 cm



DIV1929 pasta plate / Pastateller 29 cm



ISC0835 tea cup / Tasse 35 cl
 ISB0815 coffee cup / Tasse 15 cl
 ISB0808 espresso cup / tasse 8 cl
 ISC1716 saucer / Untertasse 16 cm
 ISB1714 saucer / Untertasse 14 cm
 ISB1711 saucer / Untertasse 11 cm



ISC1923 plate deep / Teller tief 23 cm
 ISC1926 pasta plate / Pastateller 26 cm




ISC1413 bowl / Schale 13 cm
 ISC1716 saucer / Untertasse 16 cm
 ISC1416 bowl / Schale 16 cm



ISB2131 plate flat / Teller flach 31 cm
 ISB2128 plate flat / Teller flach 28 cm
 ISB2126 plate flat / Teller flach 26 cm
 ISB2123 plate flat / Teller flach 23 cm
 ISB2120 plate flat / Teller flach 20 cm

POINTS



Points white
X8858



ISC1917 plate deep / Teller tief 17 cm
 ISC1923 plate deep / Teller tief 23 cm
 ISC1926 pasta plate / Pastateller 26 cm



ISC2130 plate flat / Teller flach 30 cm
 ISC2127 plate flat / Teller flach 27 cm
 ISC2124 plate flat / Teller flach 24 cm
 ISC2121 plate flat / Teller flach 21 cm
 ISC2116 plate flat / Teller flach 16 cm

POINTS