

le Choco

café

le Choco

Light coupe shapes in three different colors make a unique opportunity for a presentation and serving desserts or snacks in cafés. The combinations of the colors as of the porcelain and as of the food create remarkable and unforgettable experience even for a short a date or meeting.

Just take your time and sit by the window at the café and enjoy the beauty of the porcelain and taste of the food watching the people rushing on the street.

Schlichte Coupeformen in drei verschiedenen Farbtönen schaffen einzigartige Möglichkeiten der Präsentation von Desserts oder Snacks. Durch die Farbkombinationen erzielen Sie unvergessliche Eindrücke - sei es bei einer kurzen Verpflegung oder beim gemütlichem Beisammensein. Nehmen Sie sich Zeit für eine Verschnaufpause im Café, beobachten Sie das lebhaftes Treiben auf den Strassen und geniessen Sie feinste Speisen - angerichtet auf wunderschönem Porzellan.



le Choco



CHC2116
plate flat / Teller flach
16 cm



CHC2124
plate flat / Teller flach
24 cm



CHC2130
plate flat / Teller flach
30 cm



CHC2121
plate flat / Teller flach
21 cm



CHC2127
plate flat / Teller flach
27 cm



CHB2127
plate flat / Teller flach
27 cm



CHB2124
plate flat / Teller flach
24 cm



CHB2121
plate flat / Teller flach
21 cm



CHN2127
plate flat / Teller flach
27 cm



CHN2121
plate flat / Teller flach
21 cm



CHC1926
pasta plate / Pastateller
26 cm



CHB1926
pasta plate / Pastateller
26 cm



CHN1926
pasta plate / Pastateller
26 cm



CHC3032
oval plate / Platte oval
32 cm



CHC3028
oval plate / Platte oval
28 cm



CHC3020
oval plate / Platte oval
20 cm



CHN3020
oval plate / Platte oval
20 cm



CHB3028
oval plate / Platte oval
28 cm



CHC1416
bowl / Schale
16 cm



CHN1413
bowl / Schale
13 cm



CHC1413
bowl / Schale
13 cm



CHB1413
bowl / Schale
13 cm



CHC1923
plate deep / Teller tief
23 cm



CHB1923
plate deep / Teller tief
23 cm

le Choco



CHC0815
coffee cup / Tasse
15 cl



CHB1816
saucer / Untertasse
16 cm

CHC0825
tea cup / Tasse
15 cl



CHN1816
saucer / Untertasse
16 cm

CHC0808
espresso / Tasse
8 cl



CHB1711
saucer / Untertasse
11 cm

CHC1711
saucer / Untertasse
11 cm

CHN1711
saucer / Untertasse
11 cm



CHC1816
saucer / Untertasse
16 cm

CHC4260
lid / Deckel

CHC0835
tea cup / Tasse
35 cl



CHC1716
saucer / Untertasse
16 cm



CHC4160
pot / Kanne
60 cl

CHC0622
coffee cup / Tasse
22 cl



CHC17A4
saucer / Untertasse
14 cm

CHC9418
oil & vinegar
Karaffe Öl & Essig
18 cl

CHB9418
oil & vinegar
Karaffe Öl, Essig

CHB5000 / CHC5030
salt shaker & pepper shaker
Salzstreuer & Pfefferstreuer



CHB9412
votive / Kerzenhalter



CHC9412
votive / Kerzenhalter



CHN9412
votive / Kerzenhalter



CHC2123
plate flat / Teller flach
23 cm