



# JOSEFINE

brevity is the soul of wit  
In der Kürze liegt die Würze



# JOSEFINE



STR 2119  
PLATE FLAT | TELLER FLACH  
19 cm



STR 2124  
PLATE FLAT | TELLER FLACH  
24 cm



STR 2117  
PLATE FLAT | TELLER FLACH  
17 cm



STR 2121  
PLATE FLAT | TELLER FLACH  
21 cm



STR 2126  
PLATE FLAT | TELLER FLACH  
26 cm



STR 2128  
PLATE FLAT | TELLER FLACH  
28 cm



STR 1924  
PLATE DEEP | TELLER TIEF  
24 cm



SPZ 1419  
DISH | SCHALE  
19 cm

JOS 1125  
SOUP BOWL | SUPPENTASSE  
25 cl



SPZ 1417  
DISH | SCHALE  
17 cm



SPZ 1415  
DISH | SCHALE  
15 cm

JOS 1717  
SAUCER | UNTERTASSE  
17 cm



SPZ 1424  
DISH | SCHALE  
24 cm



SPZ 1422  
DISH | SCHALE  
22 cm



SPZ 1426  
DISH | SCHALE  
26 cm





# JOSEFINE

JOS 0222  
CUP | TASSE 22 cl



JOS 0209  
CUP | TASSE 9 cl



JOS 0218  
CUP | TASSE 18 cl



JOS 1712  
SAUCER | UNTERTASSE  
12 cm

JOS 1714  
SAUCER | UNTERTASSE  
14 cm

JOS 1715  
SAUCER | UNTERTASSE  
15 cm

JOS 3960  
COVER | DECKEL



JOS 3602  
CREAMER | GIESSER  
2 cl

JOS 3604  
CREAMER | GIESSER  
4 cl



JOS 3510  
CREAMER | GIESSER  
10 cl

JOS 3550  
CREAMER | GIESSER  
50 cl



JOS 3860  
COFFEE POT | KAFFEEKANNE  
60 cl



JOS 3530  
CREAMER | GIESSER  
30 cl

JOS 3910  
COVER | DECKEL



JOS 3960  
COVER | DECKEL



JOS 4145  
TEA POT | TEEKANNE  
45 cl

JOS 3410  
CREAMER | GIESSER  
1,2 l

JOS 3930  
COVER | DECKEL



JOS 3830  
COFFEE POT | KAFFEEKANNE  
30 cl

JOS 3710  
COFFEE POT | KAFFEEKANNE  
1 l

