

TRIC

DESIGN BY MICHAEL SIEGER



Color and freshness

-
- Ideal for cozy table settings**
-
- Unique gourmet deep plates**
-
- Suggested with Sambonet cutlery with Vintage or Antique finish**

Farben und Frische

-
- Ideal für wohnliche Tischarrangements
-
- Interessante tiefe Gourmet-Teller
-
- Gut kombinierbar mit Sambonet-Besteck in Antique- oder Vintage-Finish

Colore e freschezza

-
- Ideale per apparecchiature accoglienti
-
- Interessante piatto fondo gourmet
-
- Abbinamento suggerito: posateria Sambonet con finitura Antique o Vintage

Couleur et fraîcheur

-
- Idéale pour des mises en place conviviales
-
- Assiette gourmet creuse originale
-
- S'associe idéalement aux couverts Sambonet finition Antique ou Vintage



Arzberg

GERMANY

HOTEL & RESTAURANT SERVICE

TRIC



PORCELAIN ARZBERG - TRIC SOFT ROSE
CUTLERY SAMBONET - FLAT VINTAGE PVD COPPER





TRIC

PORCELAIN ARZBERG - TRIC SOFT ROSE
CUTLERY SAMBONET - FLAT VINTAGE PVD COPPER



Arzberg

GERMANY

HOTEL & RESTAURANT SERVICE

TRIC



PORCELAIN ARZBERG - TRIC AMARENA, YELLOW AND BLUE
CUTLERY SAMBONET - FLAT VINTAGE

TRIC

SHAPE / FORM / FORMA / FORME
49700

DECOR / DEKOR / DECORO / DÉCORATION
800001 WHITE

 Microwave-safe

 Dishwasher safe



WHITE
800001

SOFT ROSE
640152

AMARENA
640151

HOT
670186




Plate flat

Teller flach
Piatto piano
Assiette plate

10022 Ø 22 cm - Ø 8⁵/₈ in.
10027 Ø 27 cm - Ø 10⁵/₈ in.
10982 Ø 32 cm - Ø 12⁵/₈ in.



Plate flat

Teller flach
Piatto piano
Assiette plate

10018 Ø 18 cm - Ø 7¹/₈ in.



Plate deep

Teller tief
Piatto fondo
Assiette creuse

10121 Ø 21 cm H 3,5 cm - Ø 8¹/₄ in. H 1³/₈ in.



Gourmet plate deep / bowl

Gourmetteller tief / Schale
Piatto fondo gourmet
Coupe assiette gourmet

15726 Ø 30 cm H 5 cm - Ø 11³/₄ in. H 2 in.



FRESH
670203

YELLOW
606544

GREEN
606545

Arzberg

GERMANY

HOTEL & RESTAURANT SERVICE



BLUE
606546

OCEAN
670206

COOL
670187



Soup bowl

Suppenschale
Coppetta brodo
Bol à soup

15385 Ø 21 cm H 5 cm
Ø 8¼ in. H 2 in.



Platter oval

Platte oval
Piatto ovale
Plat ovale

12733 33 x 22 cm - 13 x 8⅝ in.



Square platter

Platte quadratisch
Piatto quadrato
Plat carré

11957 7 x 7 cm - 2¾ x 2¾ in.



Platter flat rectangular

Platter flach rechteckig
Piatto piano rettangolare
Plat plate rectangulaire

12201 15 x 12 cm - 5⅞ x 4¾ in.
12202 20 x 15 cm - 7⅞ x 5⅞ in.
12203 33 x 21 cm - 13 x 8¼ in.



Bowl, conical

Schale konisch
Coppa conica
Bol conique

15209 Ø 9 cm H 4 cm 0,13 L
Ø 3½ in. H 1½ in. 4⅜ oz.
15212 Ø 12 cm H 6,5 cm 0,35 L
Ø 4¾ in. H 2½ in. 11⅞ oz.
15215 Ø 15 cm H 6 cm 0,70 L
Ø 5⅞ in. H 2⅜ in. 23⅝ oz.
15221 Ø 21 cm H 7 cm 1,70 L
Ø 8¼ in. H 2¾ in. 57½ oz.



Bowl

Schale
Coppa
Bol

13312 Ø 12 cm H 5,5 cm 0,33 L
Ø 4¾ in. H 2⅛ in. 11⅛ oz.
13315 Ø 15 cm H 7,5 cm 0,80 L
Ø 5⅞ in. H 3 in. 27 oz.
13321 Ø 21 cm H 9,5 cm 2,00 L
Ø 8¼ in. H 3¾ in. 67⅝ oz.
13328 Ø 28 cm H 12 cm 4,50 L
Ø 11 in. H 4¾ in. 152½ oz.

TRIC

TRIC

SHAPE / FORM / FORMA / FORME
49700

DECOR / DEKOR / DECORO / DÉCORATION
800001 WHITE

WHITE
800001

SOFT ROSE
640152

AMARENA
640151

HOT
670186



Microwave-safe



Dishwasher safe



Teapot

Teekanne
Teiera
Théière

14235 Ø 15,5 cm H 13 cm 1,10 L
Ø 6⁵/₈ in. H 5¹/₈ in. 37¹/₄ oz.

14232 Teapot lid *

Warmer

Stövchen
Scaldino
Réchaud

15670 Ø 17 cm H 7 cm
Ø 6³/₄ in. H 2³/₄ in.



Sugar shaker

Zuckerstreuer
Dosa zucchero
Sucrier à saupoudrer

14395 Ø 7 cm H 15 cm 0,20 L
Ø 2³/₄ in. H 5⁷/₈ in. 6³/₄ oz.



Sugar bowl with lid

Zuckerdose mit Deckel
Zuccheriera con coperchio
Sucrier avec couvercle

14307 Ø 8 cm H 10 cm 0,23 L
Ø 3¹/₈ in. H 3⁷/₈ in. 7³/₄ oz.

14309 Only Lid



Napkin Ring/Egg cup (upper part)

Serviettenring/Eierbecher-Oberteil
Portatovagliolo/portauovo (parte superiore)
Rond de serviette/Coquetier (partie supérieure)

15053 Ø 5 cm H 6 cm
Ø 2 in. H 2³/₈ in.

Egg cup Napkin ring 15053 + Saucer 14721



Creamer

Gießer
Cremiera
Crémier

14430 Ø 6,5 cm H 10 cm 0,20 L
Ø 2¹/₂ in. H 3⁷/₈ in. 6³/₄ oz.



Round soufflé

Auflaufform rund
Soufflé tondo
Moule à gratin rond

15228 Ø 28 cm H 4,5 cm
Ø 11 in. H 1³/₄ in.



Salt shaker

Salzstreuer
Spargisale
Salière

15030 Ø 4 cm H 6 cm
Ø 1⁵/₈ in. H 2³/₈ in.



Pepper shaker

Pfefferstreuer
Spargipepe
Poivrier

15035 Ø 4 cm H 6 cm
Ø 1⁵/₈ in. H 2³/₈ in.



FRESH
670203

YELLOW
606544

GREEN
606545

Arzberg

GERMANY

HOTEL & RESTAURANT SERVICE



BLUE
606546

OCEAN
670206

COOL
670187

TRIC



Cup
Obertasse
Tazza
Tasse

14722 Ø 6 cm H 6 cm 0,10 L
Ø 2³/₈ in. H 2³/₈ in 3³/₈ oz.



Cup tall
Obertasse hoch
Tazza alta
Tasse haute

15577 Ø 7 cm H 8,5 cm 0,18 L
Ø 2³/₄ in. H 3³/₈ in 6¹/₈ oz.



SUITABLE FOR
14722 - 15577
↑

Saucer
Untertasse
Piattino
Soucoupe

14721 Ø 11 cm - Ø 4³/₈ in.



Cup
Obertasse
Tazza
Tasse

14642 Ø 10 cm H 5 cm 0,22 L
Ø 3⁷/₈ in. H 2 in. 7¹/₂ oz.



Cup
Obertasse
Tazza
Tasse

14742 Ø 8 cm H 6,5 cm 0,20 L
Ø 3¹/₈ in. H 2¹/₂ in. 6³/₄ oz.



Cup
Obertasse
Tazza
Tasse

14852 Ø 12 cm H 6,5 cm 0,35 L
Ø 4³/₄ in. H 2¹/₂ in. 11⁷/₈ oz.



Mug with handle
Becher mit Henkel
Mug con manico
Gobelet avec anse

15505 Ø 8 cm H 9,5 cm 0,32 L
Ø 3¹/₈ in. H 3³/₄ in. 10⁷/₈ oz.



SUITABLE FOR
14642 - 14742 - 14852 - 15505
↑

Saucer
Untertasse
Piattino
Soucoupe

14741 Ø 15 cm - Ø 5⁷/₈ in.